

DIMENSIONAL DATA SHEETS

Stainless Steel Flue Fittings

Ø80, Ø100 and Ø130mm

WARNINGS

Nortek Global HVAC (UK) Limited equipment must be installed and maintained in accordance with the requirements of the Codes of Practice or rules in force.

Improper installation, adjustment, alteration, service or maintenance can cause property damage, injury or death.

Read instructions before installing or servicing this equipment.

Reznor® is a registered trademark of Nortek Global HVAC, LLC.


Contents

Ø80MM FLUE SYSTEM	3
Ø80mm Pipe 931mm Long (Part Number 33-54-001-FLUE16).....	4
Ø80mm Pipe 431mm Long (Part Number 33-54-002-FLUE17).....	5
Ø80mm Pipe 264mm Long (Part Number 33-54-003-FLUE18).....	6
Ø80mm Elbow 45° (Part Number 33-54-004-FLUE19).....	7
Ø80mm Elbow 90° (Part Number 33-54-005-FLUE20).....	8
Ø80mm Horizontal Terminal (Part Number 33-54-006-FLUE21)	9
Ø80mm Weathering Cap (Part Number 33-54-007-FLUE22)	10
Ø80mm Horizontal Concentric Terminal (Part Number 33-55-009-FLUE27)	11
Ø80mm Vertical Concentric Terminal (Part Number 33-55-010-FLUE28)	12
 Ø100MM FLUE SYSTEM	 13
Ø100mm Pipe 931mm Long (Part Number 33-54-101-FLUE1).....	14
Ø100mm Pipe 431mm Long (Part Number 33-54-102-FLUE23).....	15
Ø100mm Pipe 264mm Long (Part Number 33-54-103-FLUE24).....	16
Ø100mm Elbow 45° (Part Number 33-54-104-FLUE2).....	17
Ø100mm Elbow 90° (Part Number 33-54-105-FLUE3).....	18
Ø100mm Horizontal Terminal (Part Number 33-54-106-FLUE25)	19
Ø100mm Weathering Cap (Part Number 33-54-107-FLUE4)	20
Ø100mm Horizontal Concentric Terminal (Part Number 33-55-106-FLUE13)	21
Ø100mm Vertical Concentric Terminal (Part Number 33-55-107-FLUE11)	22
 Ø130MM FLUE SYSTEM	 23
Ø130mm Pipe 931mm Long (Part Number 33-54-201-FLUE5).....	24
Ø130mm Pipe 431mm Long (Part Number 33-54-202-FLUE6).....	25
Ø130mm Pipe 264mm Long (Part Number 33-54-203-FLUE7).....	26
Ø130mm Elbow 45° (Part Number 33-54-204-FLUE8).....	27
Ø130mm Elbow 90° (Part Number 33-54-205-FLUE9).....	28
Ø130mm Horizontal Terminal (Part Number 33-54-206-FLUE26)	29
Ø130mm Weathering Cap (Part Number 33-54-207-FLUE10)	30
Ø130mm Horizontal Concentric Terminal (Part Number 33-55-206-FLUE12)	31
Ø130mm Vertical Concentric Terminal (Part Number 33-55-207-FLUE29)	32
 FLUE CUTTING INSTRUCTIONS	 33

80mm Flue System

Ø80MM FLUE SYSTEM


ØDN	80
-----	----



Ø80mm Pipe 931mm Long
(Part Number 33-54-001-FLUE16)

Ø80MM FLUE SYSTEM


ØDN	80
-----	----



Ø80mm Pipe 431mm Long
(Part Number 33-54-002-FLUE17)

Ø80MM FLUE SYSTEM


ØDN	80
-----	----



Ø80mm Pipe 264mm Long
(Part Number 33-54-003-FLUE18)

Ø80MM FLUE SYSTEM


ØDN	80
-----	----



Ø80mm Elbow 45°
(Part Number 33-54-004-FLUE19)

Ø80MM FLUE SYSTEM



ØDN	80
-----	----



Ø80mm Elbow 90°
(Part Number 33-54-005-FLUE20)

Ø80MM FLUE SYSTEM


ØDN	80
-----	----



Ø80mm Horizontal Flue Terminal
(Part Number 33-54-006-FLUE21)

Ø80MM FLUE SYSTEM

ØDN	80
-----	----




Ø80mm Weathering Cap
(Part Number 33-54-007-FLUE22)

Ø80MM FLUE SYSTEM


ØDN	80
D.Ext	125




1x011 EVJ



1x1B9 EVJ



2x134 EV





1x070 SW




Ø80mm Horizontal Concentric Terminal
(Part Number 33-55-009-FLUE27)

Ø80MM FLUE SYSTEM

ØDN	80
D.Ext	125



1x070 SW




Ø80mm Vertical Concentric Terminal
(Part Number 33-55-010-FLUE28)

100mm Flue System

Ø100MM FLUE SYSTEM


ØDN	100
-----	-----



Ø100mm Pipe 931mm Long
(Part Number 33-54-101-FLUE1)

Ø100MM FLUE SYSTEM


ØDN	100
-----	-----



Ø100mm Pipe 431mm Long
(Part Number 33-54-102-FLUE23)

Ø100MM FLUE SYSTEM


ØDN	100
-----	-----



Ø100mm Pipe 264mm Long
(Part Number 33-54-103-FLUE24)

Ø100MM FLUE SYSTEM


ØDN	100
-----	-----



Ø100mm Elbow 45°
(Part Number 33-54-104-FLUE2)


Ø100MM FLUE SYSTEM

ØDN	100
-----	-----



Ø100mm Elbow 90°
(Part Number 33-54-105-FLUE3)


Ø100MM FLUE SYSTEM



Ø100mm Horizontal Flue Terminal
(Part Number 33-54-106-FLUE25)

Ø100MM FLUE SYSTEM


ØDN	100
-----	-----




Ø100mm Weathering Cap
(Part Number 33-54-107-FLUE4)

Ø100MM FLUE SYSTEM


ØDN	100
ØDext	150




1x011 EVJ




1x1B9 EVJ



2x134 EV



1x070 SW




Ø100mm Horizontal Concentric Terminal
(Part Number 33-55-106-FLUE13)


Ø100MM FLUE SYSTEM

ØDN	100
ØDext	150

1x010 EVJ



1x1B9 EVJ



1x070 SW




Ø100mm Vertical Concentric Terminal
(Part Number 33-55-107-FLUE11)

130mm Flue System

Ø130MM FLUE SYSTEM


ØDN	130
-----	-----



Ø130mm Pipe 931mm Long
(Part Number 33-54-201-FLUE5)

Ø130MM FLUE SYSTEM


ØDN	130
-----	-----



Ø130mm Pipe 431mm Long
(Part Number 33-54-202-FLUE6)

Ø130MM FLUE SYSTEM


ØDN	130
-----	-----



Ø130mm Pipe 264mm Long
(Part Number 33-54-203-FLUE7)

Ø130MM FLUE SYSTEM


ØDN	130
-----	-----



Ø130mm Elbow 45° Long
(Part Number 33-54-204-FLUE8)



Ø130MM FLUE SYSTEM

ØDN	130
-----	-----



Ø130mm Elbow 90°
(Part Number 33-54-205-FLUE9)


Ø130MM FLUE SYSTEM



Ø130mm Horizontal Flue Terminal
(Part Number 33-54-206-FLUE26)

Ø130MM FLUE SYSTEM

ØDN	130
-----	-----




Ø130mm Weathering Cap
(Part Number 33-54-207-FLUE10)

Ø130MM FLUE SYSTEM


ØDN	130
ØDext	200




1x011 EVJ




1x1B9 EVJ



2x134 EV





1x070 SW



Ø130mm Horizontal Concentric Terminal
(Part Number 33-55-206-FLUE12)

Ø130MM FLUE SYSTEM


ØDN	130
D.Ext	200



1x070 SW




1x1B9 EVJ



Ø130mm Vertical Concentric Terminal
(Part Number 33-55-207-FLUE29)

RANGE = SW (Ø80-300)



 Cut the item to length using a radial saw or a metal hacksaw taking care not to make it oval or deform it.

* In case SWJ smoothen sharp edges

Notes

Notes



Nortek Global HVAC (UK) LTD

Fens Pool Avenue, Brierley Hill
West Midlands, DY5 1QA
United Kingdom

Tel: +44 (0) 1384 489 700
Fax: +44 (0) 1384 489 707

Email: reznorsales@nortek.com

Web: www.reznor.eu

AFFIX AGENTS DETAILS HERE